



What's In The Box




Dish




Wedge Mount



Power Supply



Power Supply Mount



Starlink Cable
25 m
(82 ft)



Ethernet Cable
5 m
(16.5 ft)



AC Cable (Power Supply)
1.8 m
(6 ft)



Sealing Washers
4x



Washers
8x



Lock Nuts
4x



Machine Screws
4x
38.1 mm (1.5 in)



Socket Head Bolts
2x
13 mm (1/2 in)



Shoulder Bolts
2x




Thread Locker



Silicone Sealant

Recommended Tools



Drill / Impact Driver



Drill Bit
6.5 mm (1/4 in)



Pencil



7/16 in Socket




7/16 in Wrench



Socket Wrench



5/32 in Hex Key



3/16 in Hex Key


1 | Download the Starlink App

Scan the QR code to download the Starlink App.



2 | Mounting Location


Your Starlink needs a clear view of the sky so it can stay connected with satellites as they move overhead. Objects that obstruct the connection between your Starlink and the satellite, such as a tree branch, pole, or roof, will cause service interruptions. Use the obstruction tool in the App to ensure you have selected a suitable mounting location.



3 | Mark the Pilot Holes

Mark the location of the four holes on your Wedge Mount using a pen or pencil.


The included machine screws can accommodate mounting surfaces up to 11.44 mm (0.3 in) thick.



4 | Drill the Pilot Holes

Drill the holes with a 6.5 mm (0.25 in) drill bit.


Remove burrs around holes and make sure the surface is free of debris.



5 | Apply Sealant and Screw in Wall Mount


Place rubber washers over holes followed by mount. Install a washer on each of the four machine screws, liberally apply silicone sealant on the threads, and insert screws through mount and pre-drilled holes.

Install a washer and nut on the end of each machine screw and secure mount to surface. Use a 7/16 in socket and wrench to tighten screws to snug plus 1/4 turn. Do not overtighten.



6 | Install Shoulder Bolt


Install shoulder bolts into threaded holes near the cable port. Use a 5/32 in hex key to tighten bolts to hand tight.



7 | Lock Starlink onto Mount

Align shoulder bolts into the keyway on the bottom of the mount. Push down and slide Starlink forward to lock into place.


Once secured, fully tighten shoulder bolts.



8 | Secure Starlink

Wet threads of the 12.7 mm (0.5 in) socket head bolts with thread locker and install into the two remaining holes to secure Starlink. Use the 3/16 in hex key to tighten screws to snug plus 1/4 turn. Do not overtighten.

Ensure you are using the 12.7 mm (0.5 in) length bolts. Longer bolts can damage Starlink.



9 | **Connect and Align Starlink**

Plug the Starlink cable into the port on the bottom of the Starlink.

If you have a Starlink router, step through the Starlink install process on the Starlink App.

If you have a compatible third-party router, follow the router's set up instructions.

