www. Motorcyclefudio.com

HDHU.14 Firmware Update

January 3 Ist, 2022



1. Download the HDHU. I 4 <u>Firmware</u> **Update** and Save to Computer.

After downloading, make sure the compressed files are unzipped and are copied onto a blank USB Flash Drive (64GB Max) on the Root Directory File of USB Flash Drive

2. Insert USB stick and select the "Settings Icon" from the Home Screen



3. Select <u>"System Seltings"</u> Tab at top, then next screen select **"About"** button





4. Select <u>"Update"</u> and on next screen select <u>"Update"</u> Again





5. ((Wait for both Updates to complete))
Headunit will restart itself once both
updates are complete. New Firmware Info:

MCU – HDHU-14-220126 SOC – HDHU.14-220124-12:00

Firmware Improvements:

- Adds 10-Second Amplifier Turn-on Option
- Defaults Key-Beep Alert to "Off"
- Balances the Source Levels (USB, BT)
- Increases Overall Level Before Clipping
- Reduces Intermittent Data Feedback

Need Help? Contact Tech-Support

Tech-Support

Or 800.832.4647 Monday-Friday

8:30AM – 4:30PM Pacific Standard

If Tech Support is busy, please leave a message and you will get a return call withing 48 hours of being received. For Faster Service Email Us